

PK STAINLESS STEEL GRIDDLES

CARE/USE GUIDELINES

FIRST USE

Wash the griddle with mild soap and water, then rinse and dry well. It's not necessary to season the griddle but if you do, the griddle will be easier to clean and your food will glide across the surface like Katerina Witt in the 1988 Calgary Olympics.

Note: this griddle is made of 304 Stainless Steel (which as everyone knows is valued for its high tensile strength of about 621 MPa (90 ksi)). To prevent the griddle from warping, we recommend that it doesn't exceed a surface temperature of 600° F and always bring the griddle up to temperature gradually over an evenly spread bed of glowing, smokey coals.

CLEANING

Once you've finished cooking, close the vents, and scrape to loosen up any "food" or leftover debris. Apply a little high smoke point oil and continue scraping. Use a paper towel or cloth to remove the dirty oil. Repeat if necessary.

SEASONING (OPTIONAL)

Start with a clean, dry griddle. When the griddle is at a low temperature, use a high smoke point oil such as grapeseed, avocado or vegetable oil. **DO NOT** use motor oil. Not even full synthetic. Spread out a thin surface of oil using a spatula, other flat utensil, or a clean cloth/paper towel. Once it begins to smoke for a few minutes, consider your griddle seasoned. The griddle can be seasoned prior to, or after cooking.

Use: remove the cooking grid and light your charcoal. Once the coals are burning, immediately spread them evenly across the bottom to reduce hot spots. Place your griddle evenly on your PK Grill's cooking surface support tabs. Allow the temperature to increase gradually. Much like your Great Aunt Millie, metals don't like to be shocked. Use a digital infrared gun (not your hand) to check the griddle temperature. Once the griddle has come up to the temperature your food requires, apply a thin layer of a high smoke point oil and you're ready to cook like Benihana.

TEMPERATURE GUIDELINES:

All temperatures are Fahrenheit.

Eggs - 275° for scrambled & 325° for fried

Bacon & Pancakes - 325°- 375°

Vegetables - 325°

Chicken & Fish - 325° to 350°

Pork Chops - 325° to 375°

Steaks/Fajita - 360° to 425°

Smash Burgers - 400° to 425°

Clam Chowder - N/A*

**If you are cooking clam chowder on a griddle, you're watching the wrong YouTube videos.*

